

checkCIF/PLATON report

You have not supplied any structure factors. As a result the full set of tests cannot be run.

THIS REPORT IS FOR GUIDANCE ONLY. IF USED AS PART OF A REVIEW PROCEDURE FOR PUBLICATION, IT SHOULD NOT REPLACE THE EXPERTISE OF AN EXPERIENCED CRYSTALLOGRAPHIC REFEREE.

No syntax errors found. CIF dictionary Interpreting this report

Datablock: MUF-93-60h-59pc

Bond precision: = 0.0000 Å

Wavelength=0.71075

Cell: a=17.115(9) b=17.115(9) c=17.115(9)
 alpha=90 beta=90 gamma=90
Temperature: 100 K

	Calculated	Reported
Volume	5013(8)	5013(8)
Space group	P -4 3 m	P -4 3 m
Hall group	P -4 2 3	P -4 2 3
Moiety formula	C4.54 H2.59 Co0.10 N0.25 00.86 Zn0.17	1(C84 H48 N6 O13 Zn4), 1(C24.88 H14.22 Co2.37 O7.7)
Sum formula	C4.54 H2.59 Co0.10 N0.25 00.86 Zn0.17	C108.87 H62.22 Co2.37 N6 O20.70 Zn4
Mr	91.13	2186.59
Dx, g cm ⁻³	0.725	0.724
Z	24	1
Mu (mm ⁻¹)	0.699	0.699
F000	1107.1	1107.0
F000'	1109.54	
h, k, lmax	14, 14, 14	14, 14, 14
Nref	628[360]	622
Tmin, Tmax		0.613, 0.745
Tmin'		

Correction method= # Reported T Limits: Tmin=0.613 Tmax=0.745
AbsCorr = MULTI-SCAN

Data completeness= 1.73/0.99 Theta(max)= 17.208

R(reflections)= 0.1642(456) wR2(reflections)= 0.3852(622)

S = 1.605 Npar= 99

The following ALERTS were generated. Each ALERT has the format
test-name_ALERT_alert-type_alert-level.
Click on the hyperlinks for more details of the test.

 Alert level A

THETM01_ALERT_3_A The value of $\sin(\theta_{\max})/\lambda$ is less than 0.550
Calculated $\sin(\theta_{\max})/\lambda = 0.4162$
PLAT090_ALERT_3_A Poor Data / Parameter Ratio ($Z_{\max} > 18$) 3.64 Note

 Alert level B

PLAT049_ALERT_1_B Calculated Density Less Than 1.0 gcm⁻³ 0.7245 Check
PLAT082_ALERT_2_B High R1 Value 0.16 Report
PLAT084_ALERT_3_B High wR2 Value (i.e. > 0.25) 0.39 Report
PLAT245_ALERT_2_B U(iso) H13 Smaller than U(eq) N1 by 0.095 Ang**2
PLAT315_ALERT_2_B Singly Bonded Carbon Detected (H-atoms Missing). C14 Check
PLAT315_ALERT_2_B Singly Bonded Carbon Detected (H-atoms Missing). C34 Check
PLAT987_ALERT_1_B The Flack x is >> 0 - Do a BASF/TWIN Refinement Please Check

 Alert level C

STRVA01_ALERT_4_C Flack test results are ambiguous.
From the CIF: `_refine_ls_abs_structure_Flack` 0.320
From the CIF: `_refine_ls_abs_structure_Flack_su` 0.040
PLAT041_ALERT_1_C Calc. and Reported SumFormula Strings Differ Please Check
PLAT053_ALERT_1_C Minimum Crystal Dimension Missing (or Error) ... Please Check
PLAT054_ALERT_1_C Medium Crystal Dimension Missing (or Error) ... Please Check
PLAT055_ALERT_1_C Maximum Crystal Dimension Missing (or Error) ... Please Check
PLAT077_ALERT_4_C Unitcell Contains Non-integer Number of Atoms .. Please Check
PLAT161_ALERT_4_C Missing or Zero s.u. (esd) on x-coordinate for . 01 Check
PLAT161_ALERT_4_C Missing or Zero s.u. (esd) on x-coordinate for . ZN1 Check
PLAT161_ALERT_4_C Missing or Zero s.u. (esd) on x-coordinate for . 02 Check
PLAT161_ALERT_4_C Missing or Zero s.u. (esd) on x-coordinate for . C10 Check
PLAT161_ALERT_4_C Missing or Zero s.u. (esd) on x-coordinate for . C11 Check
PLAT161_ALERT_4_C Missing or Zero s.u. (esd) on x-coordinate for . C12 Check
PLAT161_ALERT_4_C Missing or Zero s.u. (esd) on x-coordinate for . C13 Check
PLAT161_ALERT_4_C Missing or Zero s.u. (esd) on x-coordinate for . C14 Check
PLAT161_ALERT_4_C Missing or Zero s.u. (esd) on x-coordinate for . N1 Check
PLAT161_ALERT_4_C Missing or Zero s.u. (esd) on x-coordinate for . C15 Check
PLAT161_ALERT_4_C Missing or Zero s.u. (esd) on x-coordinate for . C16 Check
PLAT161_ALERT_4_C Missing or Zero s.u. (esd) on x-coordinate for . C17 Check
PLAT161_ALERT_4_C Missing or Zero s.u. (esd) on x-coordinate for . C18 Check
PLAT161_ALERT_4_C Missing or Zero s.u. (esd) on x-coordinate for . C19 Check
PLAT161_ALERT_4_C Missing or Zero s.u. (esd) on x-coordinate for . C20 Check
PLAT161_ALERT_4_C Missing or Zero s.u. (esd) on x-coordinate for . C21 Check
PLAT161_ALERT_4_C Missing or Zero s.u. (esd) on x-coordinate for . C02 Check
PLAT161_ALERT_4_C Missing or Zero s.u. (esd) on x-coordinate for . 03 Check
PLAT161_ALERT_4_C Missing or Zero s.u. (esd) on x-coordinate for . 04 Check
PLAT161_ALERT_4_C Missing or Zero s.u. (esd) on x-coordinate for . C30 Check
PLAT161_ALERT_4_C Missing or Zero s.u. (esd) on x-coordinate for . C31 Check
PLAT161_ALERT_4_C Missing or Zero s.u. (esd) on x-coordinate for . C32 Check
PLAT161_ALERT_4_C Missing or Zero s.u. (esd) on x-coordinate for . C33 Check
PLAT161_ALERT_4_C Missing or Zero s.u. (esd) on x-coordinate for . C34 Check
PLAT162_ALERT_4_C Missing or Zero s.u. (esd) on y-coordinate for . 01 Check
PLAT162_ALERT_4_C Missing or Zero s.u. (esd) on y-coordinate for . ZN1 Check
PLAT162_ALERT_4_C Missing or Zero s.u. (esd) on y-coordinate for . 02 Check
PLAT162_ALERT_4_C Missing or Zero s.u. (esd) on y-coordinate for . C10 Check
PLAT162_ALERT_4_C Missing or Zero s.u. (esd) on y-coordinate for . C11 Check
PLAT162_ALERT_4_C Missing or Zero s.u. (esd) on y-coordinate for . C12 Check

PLAT162_ALERT_4_C Missing or Zero s.u. (esd) on y-coordinate for .	C13 Check
PLAT162_ALERT_4_C Missing or Zero s.u. (esd) on y-coordinate for .	C14 Check
PLAT162_ALERT_4_C Missing or Zero s.u. (esd) on y-coordinate for .	N1 Check
PLAT162_ALERT_4_C Missing or Zero s.u. (esd) on y-coordinate for .	C15 Check
PLAT162_ALERT_4_C Missing or Zero s.u. (esd) on y-coordinate for .	C16 Check
PLAT162_ALERT_4_C Missing or Zero s.u. (esd) on y-coordinate for .	C17 Check
PLAT162_ALERT_4_C Missing or Zero s.u. (esd) on y-coordinate for .	C18 Check
PLAT162_ALERT_4_C Missing or Zero s.u. (esd) on y-coordinate for .	C19 Check
PLAT162_ALERT_4_C Missing or Zero s.u. (esd) on y-coordinate for .	C20 Check
PLAT162_ALERT_4_C Missing or Zero s.u. (esd) on y-coordinate for .	C21 Check
PLAT162_ALERT_4_C Missing or Zero s.u. (esd) on y-coordinate for .	C02 Check
PLAT162_ALERT_4_C Missing or Zero s.u. (esd) on y-coordinate for .	03 Check
PLAT162_ALERT_4_C Missing or Zero s.u. (esd) on y-coordinate for .	04 Check
PLAT162_ALERT_4_C Missing or Zero s.u. (esd) on y-coordinate for .	C30 Check
PLAT162_ALERT_4_C Missing or Zero s.u. (esd) on y-coordinate for .	C31 Check
PLAT162_ALERT_4_C Missing or Zero s.u. (esd) on y-coordinate for .	C32 Check
PLAT162_ALERT_4_C Missing or Zero s.u. (esd) on y-coordinate for .	C33 Check
PLAT162_ALERT_4_C Missing or Zero s.u. (esd) on y-coordinate for .	C34 Check
PLAT163_ALERT_4_C Missing or Zero s.u. (esd) on z-coordinate for .	01 Check
PLAT163_ALERT_4_C Missing or Zero s.u. (esd) on z-coordinate for .	ZN1 Check
PLAT163_ALERT_4_C Missing or Zero s.u. (esd) on z-coordinate for .	02 Check
PLAT163_ALERT_4_C Missing or Zero s.u. (esd) on z-coordinate for .	C10 Check
PLAT163_ALERT_4_C Missing or Zero s.u. (esd) on z-coordinate for .	C11 Check
PLAT163_ALERT_4_C Missing or Zero s.u. (esd) on z-coordinate for .	C12 Check
PLAT163_ALERT_4_C Missing or Zero s.u. (esd) on z-coordinate for .	C13 Check
PLAT163_ALERT_4_C Missing or Zero s.u. (esd) on z-coordinate for .	C14 Check
PLAT163_ALERT_4_C Missing or Zero s.u. (esd) on z-coordinate for .	N1 Check
PLAT163_ALERT_4_C Missing or Zero s.u. (esd) on z-coordinate for .	C15 Check
PLAT163_ALERT_4_C Missing or Zero s.u. (esd) on z-coordinate for .	C16 Check
PLAT163_ALERT_4_C Missing or Zero s.u. (esd) on z-coordinate for .	C17 Check
PLAT163_ALERT_4_C Missing or Zero s.u. (esd) on z-coordinate for .	C18 Check
PLAT163_ALERT_4_C Missing or Zero s.u. (esd) on z-coordinate for .	C19 Check
PLAT163_ALERT_4_C Missing or Zero s.u. (esd) on z-coordinate for .	C20 Check
PLAT163_ALERT_4_C Missing or Zero s.u. (esd) on z-coordinate for .	C21 Check
PLAT163_ALERT_4_C Missing or Zero s.u. (esd) on z-coordinate for .	C02 Check
PLAT163_ALERT_4_C Missing or Zero s.u. (esd) on z-coordinate for .	03 Check
PLAT163_ALERT_4_C Missing or Zero s.u. (esd) on z-coordinate for .	04 Check
PLAT163_ALERT_4_C Missing or Zero s.u. (esd) on z-coordinate for .	C30 Check
PLAT163_ALERT_4_C Missing or Zero s.u. (esd) on z-coordinate for .	C31 Check
PLAT163_ALERT_4_C Missing or Zero s.u. (esd) on z-coordinate for .	C32 Check
PLAT163_ALERT_4_C Missing or Zero s.u. (esd) on z-coordinate for .	C33 Check
PLAT163_ALERT_4_C Missing or Zero s.u. (esd) on z-coordinate for .	C34 Check
PLAT260_ALERT_2_C Large Average Ueq of Residue Including Zn1	0.258 Check
PLAT329_ALERT_4_C Carbon Atom Hybridisation Unclear for	C13 Check
PLAT790_ALERT_4_C Centre of Gravity not Within Unit Cell: Resd. #	1 Note
C4.54 H2.59 Co0.10 N0.25 O0.86 Zn0.17	

Alert level G

FORMU01_ALERT_2_G There is a discrepancy between the atom counts in the
 _chemical_formula_sum and the formula from the _atom_site* data.
 Atom count from _chemical_formula_sum: C108.87 H62.22 Co2.37 N6 O20.7 Z
 Atom count from the _atom_site data: C80.26158 H55.09959 Co0.395968 N
 CELLZ01_ALERT_1_G Difference between formula and atom_site contents detected.
 CELLZ01_ALERT_1_G ALERT: Large difference may be due to a
 symmetry error - see SYMMG tests
 From the CIF: _cell_formula_units_Z 1
 From the CIF: _chemical_formula_sum C108.87 H62.22 Co2.37 N6 O20.70 Zn
 TEST: Compare cell contents of formula and atom_site data

atom Z*formula cif sites diff

C	108.88	80.27	28.61		
H	62.22	55.10	7.12		
Co	2.37	0.40	1.97		
N	6.00	6.00	0.00		
O	20.70	9.62	11.08		
Zn	4.00	0.67	3.33		
PLAT002_ALERT_2_G	Number of Distance or Angle	Restraints on AtSite		11	Note
PLAT003_ALERT_2_G	Number of Uiso or Uij	Restrained non-H Atoms ...		16	Report
PLAT007_ALERT_5_G	Number of Unrefined Donor-H Atoms			1	Report
PLAT012_ALERT_1_G	No	_shelx_res_checksum Found in CIF		Please	Check
PLAT042_ALERT_1_G	Calc. and Reported MoietyFormula	Strings Differ		Please	Check
PLAT045_ALERT_1_G	Calculated and Reported Z	Differ by a Factor ...	24.00	Check	
PLAT068_ALERT_1_G	Reported F000	Differs from Calcd (or Missing)...		Please	Check
PLAT072_ALERT_2_G	SHELXL First Parameter in WGHT	Unusually Large	0.20	Report	
PLAT172_ALERT_4_G	The CIF-Embedded .res File	Contains DFIX Records	11	Report	
PLAT174_ALERT_4_G	The CIF-Embedded .res File	Contains FLAT Records	2	Report	
PLAT178_ALERT_4_G	The CIF-Embedded .res File	Contains SIMU Records	2	Report	
PLAT186_ALERT_4_G	The CIF-Embedded .res File	Contains ISOR Records	3	Report	
PLAT300_ALERT_4_G	Atom Site Occupancy of Zn1	Constrained at	0.1667	Check	
PLAT300_ALERT_4_G	Atom Site Occupancy of O2	Constrained at	0.5	Check	
PLAT300_ALERT_4_G	Atom Site Occupancy of O1	Constrained at	0.0417	Check	
PLAT300_ALERT_4_G	Atom Site Occupancy of C12	Constrained at	0.5	Check	
PLAT300_ALERT_4_G	Atom Site Occupancy of C13	Constrained at	0.5	Check	
PLAT300_ALERT_4_G	Atom Site Occupancy of N1	Constrained at	0.25	Check	
PLAT300_ALERT_4_G	Atom Site Occupancy of C10	Constrained at	0.25	Check	
PLAT300_ALERT_4_G	Atom Site Occupancy of C11	Constrained at	0.25	Check	
PLAT300_ALERT_4_G	Atom Site Occupancy of C14	Constrained at	0.25	Check	
PLAT300_ALERT_4_G	Atom Site Occupancy of C15	Constrained at	0.25	Check	
PLAT300_ALERT_4_G	Atom Site Occupancy of C16	Constrained at	0.25	Check	
PLAT300_ALERT_4_G	Atom Site Occupancy of C17	Constrained at	0.25	Check	
PLAT300_ALERT_4_G	Atom Site Occupancy of C18	Constrained at	0.25	Check	
PLAT300_ALERT_4_G	Atom Site Occupancy of C19	Constrained at	0.25	Check	
PLAT300_ALERT_4_G	Atom Site Occupancy of C20	Constrained at	0.25	Check	
PLAT300_ALERT_4_G	Atom Site Occupancy of C21	Constrained at	0.25	Check	
PLAT300_ALERT_4_G	Atom Site Occupancy of H12	Constrained at	0.5	Check	
PLAT300_ALERT_4_G	Atom Site Occupancy of H13	Constrained at	0.25	Check	
PLAT300_ALERT_4_G	Atom Site Occupancy of H17	Constrained at	0.25	Check	
PLAT300_ALERT_4_G	Atom Site Occupancy of H18	Constrained at	0.25	Check	
PLAT300_ALERT_4_G	Atom Site Occupancy of H19	Constrained at	0.25	Check	
PLAT300_ALERT_4_G	Atom Site Occupancy of H20	Constrained at	0.25	Check	
PLAT300_ALERT_4_G	Atom Site Occupancy of H21	Constrained at	0.25	Check	
PLAT301_ALERT_3_G	Main Residue Disorder	(Resd 1)	100%	Note	
PLAT304_ALERT_4_G	Non-Integer Number of Atoms in	Resd 1	8.51	Check	
PLAT607_ALERT_4_G	VOID Test Skipped Due to Severe Disorder		!	Info	
PLAT779_ALERT_4_G	Suspect or Irrelevant (Bond) Angle(s) in CIF . #		13	Check	
	N1 -C13 -H13	1.555 1.555 1.555	6.70	Deg.	
PLAT779_ALERT_4_G	Suspect or Irrelevant (Bond) Angle(s) in CIF . #		14	Check	
	C13 -N1 -H13	1.555 1.555 1.555	10.90	Deg.	
PLAT789_ALERT_4_G	Atoms with Negative _atom_site_disorder_group #		33	Check	
PLAT860_ALERT_3_G	Number of Least-Squares Restraints		235	Note	
PLAT883_ALERT_1_G	No Info/Value for _atom_sites_solution_primary .		Please	Do !	
PLAT933_ALERT_2_G	Number of OMIT Records in Embedded .res File ...		1	Note	

2 **ALERT level A** = Most likely a serious problem - resolve or explain
 7 **ALERT level B** = A potentially serious problem, consider carefully
 81 **ALERT level C** = Check. Ensure it is not caused by an omission or oversight
 47 **ALERT level G** = General information/check it is not something unexpected

13 ALERT type 1 CIF construction/syntax error, inconsistent or missing data

10 ALERT type 2 Indicator that the structure model may be wrong or deficient
5 ALERT type 3 Indicator that the structure quality may be low
108 ALERT type 4 Improvement, methodology, query or suggestion
1 ALERT type 5 Informative message, check

It is advisable to attempt to resolve as many as possible of the alerts in all categories. Often the minor alerts point to easily fixed oversights, errors and omissions in your CIF or refinement strategy, so attention to these fine details can be worthwhile. In order to resolve some of the more serious problems it may be necessary to carry out additional measurements or structure refinements. However, the purpose of your study may justify the reported deviations and the more serious of these should normally be commented upon in the discussion or experimental section of a paper or in the "special_details" fields of the CIF. checkCIF was carefully designed to identify outliers and unusual parameters, but every test has its limitations and alerts that are not important in a particular case may appear. Conversely, the absence of alerts does not guarantee there are no aspects of the results needing attention. It is up to the individual to critically assess their own results and, if necessary, seek expert advice.

Publication of your CIF in IUCr journals

A basic structural check has been run on your CIF. These basic checks will be run on all CIFs submitted for publication in IUCr journals (*Acta Crystallographica*, *Journal of Applied Crystallography*, *Journal of Synchrotron Radiation*); however, if you intend to submit to *Acta Crystallographica Section C* or *E* or *IUCrData*, you should make sure that full publication checks are run on the final version of your CIF prior to submission.

Publication of your CIF in other journals

Please refer to the *Notes for Authors* of the relevant journal for any special instructions relating to CIF submission.

