
The following ALERTS were generated. Each ALERT has the format
test-name_ALERT_alert-type_alert-level.

Click on the hyperlinks for more details of the test.



Alert level C

PLAT199_ALERT_1_C	Reported _cell_measurement_temperature	(K)	293	Check
PLAT200_ALERT_1_C	Reported _diffn_ambient_temperature	(K)	293	Check
PLAT242_ALERT_2_C	Low 'MainMol' Ueq as Compared to Neighbors of		N4	Check
PLAT242_ALERT_2_C	Low 'MainMol' Ueq as Compared to Neighbors of		C7	Check
PLAT242_ALERT_2_C	Low 'MainMol' Ueq as Compared to Neighbors of		C8	Check
PLAT341_ALERT_3_C	Low Bond Precision on C-C Bonds		0.00682	Ang.



Alert level G

PLAT005_ALERT_5_G	No Embedded Refinement Details Found in the CIF		Please Do !	
PLAT045_ALERT_1_G	Calculated and Reported Z Differ by a Factor ...		0.500	Check
PLAT066_ALERT_1_G	Predicted and Reported Tmin&Tmax Range Identical		?	Check
PLAT128_ALERT_4_G	Alternate Setting for Input Space Group C2/c		I2/a	Note
PLAT794_ALERT_5_G	Tentative Bond Valency for Co1 (II)		1.82	Info
PLAT899_ALERT_4_G	SHELXL97 is Deprecated and Succeeded by SHELXL-		2019/2	Note

-
- 0 **ALERT level A** = Most likely a serious problem - resolve or explain
0 **ALERT level B** = A potentially serious problem, consider carefully
6 **ALERT level C** = Check. Ensure it is not caused by an omission or oversight
6 **ALERT level G** = General information/check it is not something unexpected
- 4 ALERT type 1 CIF construction/syntax error, inconsistent or missing data
3 ALERT type 2 Indicator that the structure model may be wrong or deficient
1 ALERT type 3 Indicator that the structure quality may be low
2 ALERT type 4 Improvement, methodology, query or suggestion
2 ALERT type 5 Informative message, check
-
-

It is advisable to attempt to resolve as many as possible of the alerts in all categories. Often the minor alerts point to easily fixed oversights, errors and omissions in your CIF or refinement strategy, so attention to these fine details can be worthwhile. In order to resolve some of the more serious problems it may be necessary to carry out additional measurements or structure refinements. However, the purpose of your study may justify the reported deviations and the more serious of these should normally be commented upon in the discussion or experimental section of a paper or in the "special_details" fields of the CIF. checkCIF was carefully designed to identify outliers and unusual parameters, but every test has its limitations and alerts that are not important in a particular case may appear. Conversely, the absence of alerts does not guarantee there are no aspects of the results needing attention. It is up to the individual to critically assess their own results and, if necessary, seek expert advice.

Publication of your CIF in IUCr journals

A basic structural check has been run on your CIF. These basic checks will be run on all CIFs submitted for publication in IUCr journals (*Acta Crystallographica*, *Journal of Applied Crystallography*, *Journal of Synchrotron Radiation*); however, if you intend to submit to *Acta Crystallographica Section C* or *E* or *IUCrData*, you should make sure that full publication checks are run on the final version of your CIF prior to submission.

Publication of your CIF in other journals

Please refer to the *Notes for Authors* of the relevant journal for any special instructions relating to CIF submission.

